SASSOON

FORMEN

TURBO-PRO HAIR CLIPPER & GROOMING KIT

Model VS7702A

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following:
Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

DANGER: Unplug unit when not in use. All appliances are electrically live even when switched off

WARNING: This appliance must not be taken into a bathroom.

- Do not immerse in water or other liquids
- Do not use in the bath, or near basins or other vessels containing water.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Take care to avoid contact between the moving blades of the unit and the skin, paying particular attention to the face, neck and hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- **IMPORTANT:** Always unplug the appliance when not in use or before cleaning. Do not leave unattended when plugged in or switched on. Do not place on any heat sensitive surface and always wallow to cool before storing away.
- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Do not use the appliance with damaged or broken attachment combs or with any teeth missing from the blades, as injury may occur.
- Use this appliance only for its intended use as described in this instruction booklet.
- This appliance is not intended for commercial use.
- Never drop or insert any object into an opening.
- Ensure appliance is switched off before plugging into the power outlet.
- Do not place appliance on any surface while it is operating.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Keep the cord away from heated surfaces.
- Do not use this appliance if the supply cord is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange.
- After use do not wrap the cord around the appliance, as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- This appliance contains Nickel Metal-Hydrate (Ni-Mh) batteries. To protect the environment, the appliance should be disposed of safely and not in household waste at the end of its useful life. Do not attempt to remove the batteries from the appliance.

TURBO-PRO HAIR CLIPPER & GROOMING KIT

Thank you for purchasing the VS For Men Turbo-Pro Clipper & Grooming Kit - an all-in-one grooming system that features an integrated comb length control for easy thumb adjustment, to provide 28 precision cutting length settings from 3mm to 36mm, with 1.5mm accuracy, plus a precision comb guide with 5 settings and an interchangeable tramliner blade.

The clipper features an innovative Smart Adjusting System™ that provides precision results, regardless of the cutting angle, allowing you to achieve any type of hair cut or style and is rechargeable for convenient corded or cordless operation.

Features:

1. Integrated comb length control for easy thumb adjustment (grooved rotary wheel)
2. 1 telescopic comb guide attachment for shorter styles 3mm – 18mm
3. 1 telescopic comb guide attachment for longer styles 21mm – 36mm
4. 1 precision comb guide attachment for fine cut adjustment (5 settings) 0.5mm – 2.5mm
5. 1 interchangeable tramliner blade to create accurate lines & detailed hair/facial hair effects
6. Turbo boost button provides 20% extra cutting power
7. Innovative Smart Adjusting System™ provides precision results at any cutting angle
8. Clipper blades – 'Hard Like Diamond' (HLD) carbon coated stainless steel moving blade and titanium coated fixed blade
9. On/off switch
10. AC power adaptor
11. Personal groomer for trimming nose and ear hair
12. Protective cover for personal groomer blade

Accessories:

13. Scissors
14. Cleaning brush
15. Barber comb
16. Lubricating oil
17. Storage pouch

INSTRUCTIONS FOR USE

- A plastic cover has been placed over the adaptor plug to protect it from damage. Remove the plastic cover before inserting into a suitable power outlet.
- Always inspect the clipper and nose & ear hair trimmer before use to ensure the cutting head is free from hair and debris and is running smoothly.

CHARGING THE CLIPPER (FOR CORDLESS OPERATION)

IMPORTANT: Before using the appliance for the first time, charge for a full 16 hour continuous charge. Maximum battery capacity will only be reached after 3 charging and discharging cycles. After 3 cycles, the clipper must still be charged for 16 hours. Ordinarily, the clipper may be charged overnight.
In order to maintain optimum capacity of the rechargeable batteries, every 3 months the clipper should be recharged for 16 hours.

To charge the clipper, place the charging cord directly into the base of the clipper.

1. Plug the AC power adaptor into a 100V – 240V power supply.
2. When the appliance is switched off, plug the AC power adaptor directly into the base of the clipper.
3. The charging light will illuminate when the adaptor is correctly inserted into the base of the clipper and connected to the mains power supply.
4. The charging light will always stay illuminated when the product is charging. Once the clipper is charged, unplug the adaptor from the mains power supply and disconnect from the appliance.
5. A full charge will supply enough power for minimum 30 minutes use.

CORDED USE – OPERATION WITH POWER CORD

1. Plug the AC power adaptor directly into the base of the clipper.
2. Plug the AC power adaptor into a 100V – 240V power supply. Switch the power supply on, and the clipper can now be used in corded operation.

NOTE: If battery power is weak, wait about 2 minutes before pushing on/off switch.

MULTI VOLTAGE

This appliance has a multi voltage feature for worldwide use. The voltage automatically converts for ease of use from 100v - 240v. This appliance has an automatic internal converter which will automatically convert the voltage without the need of a switch. A suitable plug adaptor will be required, please refer to the chart below.

Plug adaptor required	Voltage and plug adaptors	Country	Voltage setting
	British plug: 240V	Ireland, Great Britain, Singapore, South America, Hong Kong (parts only), Africa (parts only)	240V
	European plug: 240V	Asia, Europe, Middle East Noumea, Scandinavia, South America, Hong Kong (parts only)	240V
	Australian and New Zealand plug: 240V	Australia, New Zealand	240V
	American plugs: 120V	North America, Japan, Canada (parts of)	120V

TURBO BOOST FEATURE
This clipper is equipped with a turbo boost button. When activated, this will boost the motor of the clipper, by providing 20% more cutting power. This is especially useful for cutting through thicker hair.

USING THE TELESCOPIC COMB GUIDES
Your clipper comes assembled with the 3mm – 18mm telescopic comb guide attachment already installed. The integrated comb length control guide allows you to change the cutting length of your clipper with ease. For longer styles, simply remove the shorter comb guide and attach the 21mm – 36mm comb guide.

IMPORTANT: Always remove and attach the comb guides BEFORE turning the clipper on.

To remove the comb guide, first adjust the cutting length to the shortest setting (3mm for the 3mm – 18mm comb guide and 21mm for the 21mm – 36mm comb guide). Switch the product off and then push the comb guide out of the support by lifting it up with your thumb.

(NB – When using the clipper without the comb guide attachment, the cutting length will be below 3mm. The length setting shown on the side of the product will no longer be relevant when the comb guide is removed).

To attach the comb guide, first adjust the cutting length to the shortest setting (3mm for the 3mm – 18mm comb guide and 21mm for the 21mm – 36mm comb guide). Switch the product off and place the comb guide on the support by adjusting both sides to ensure they are correctly in place. Push the comb guide onto the bottom of the support until it clicks into place. The comb guide should then be secure on the support.

22 Cutting Length Settings (3mm – 36mm)
The Turbo-Pro Clipper uses an integrated comb length control which allows you to adjust the length setting to 22 different positions with 1.5mm accuracy. The 2 telescopic comb guides included with this product help to eliminate the need of changing and storing many different attachment combs.

- To use the clipper, simply adjust the cutting length by turning the grooved rotary wheel up or down to position the comb guide to the desired cutting length.
- Depending on the comb guide attached: 3mm – 18mm (shorter comb), or 21mm – 36mm (longer comb), an orange coloured arrow will show the length setting on either the right or left side of the clipper (in 1.5mm increments):

Comb Guide	Length Displayed
3mm – 18mm shorter comb guide	Left side of the clipper
21mm – 36mm longer comb guide	Right side of the clipper

The 2 telescopic comb guides included with this product offer 22 cutting length settings (in 1.5mm increments). The cutting length settings correspond to the following grade number:

Cutting Length	Comb Guide
3mm	#1
6mm	#2
9mm	#3
12mm	#4
15mm	#5
18mm	#6
21mm	#7
24mm	#8
27mm	#9
30mm	#10
33mm	#11
36mm	#12

USING THE PRECISION COMB GUIDE

The precision comb guide is designed for fine cut adjustment. It provides an ultra close cutting length which is ideal for creating designer stubble or close, cropped hair styles.

This comb is adjusted manually.
To adjust the length setting, slide the switch located on the top of the comb guide. 5 length settings are shown on the top of the comb guide.

Settings	Cutting Length
Setting 1	0.5mm
Setting 2	1mm
Setting 3	1.5mm
Setting 4	2mm
Setting 5	2.5mm

To attach the precision comb guide, remove the telescopic comb guide first by adjusting the cutting length to the shortest setting (3mm for the 3mm – 18mm comb guide and 21mm for the 21mm – 36mm comb guide). Switch the product off and then push the comb guide out of the support by lifting it up with your thumb.
Ensure that the cutting length is at the shortest setting – 3mm. Place the precision comb guide on the support by adjusting both sides to ensure they are correctly in place. Push the precision comb guide onto the bottom of the support until it clicks into place. The precision comb guide should then be secure on the support.

To remove the precision comb guide, adjust the comb guide to the shortest setting. Switch the product off and then push the precision comb guide out of the support by lifting it up with your thumb.

USING THE TRAMLINER BLADE

The tramliner blade is used for creating accurate detailing, edge lines and designer tramlines in hair and facial hair.

To attach the interchangeable tramliner blade, remove the telescopic comb guide first by adjusting the cutting length to the shortest setting (3mm for the 3mm – 18mm comb guide and 21mm for the 21mm – 36mm comb guide). Switch the product off and then push the comb guide out of the support by lifting it up with your thumb.

You will need to remove the existing blade from the clipper before using the tramliner blade. To remove the blade, hold the handle of the clipper with one hand and place your free hand on top of the clipper head, with the thumb placed at the back of the blades. Place your index finger and middle finger at the front of the blade. Using your index and middle fingers, pull the blade backwards and click off from the clipper. Place the blade in a secure place.

Attach the tramliner blade by lining up the insert with the lug at the bottom of the blade. Slant the blades forward and then click into place.

To remove the tramliner blade, hold the handle of the clipper with one hand and place your free hand on top of the clipper head, with the thumb placed at the back of the tramliner blade. Place your index finger and middle finger at the front of the tramliner blade. Using your index and middle fingers, pull the tramliner blade backwards and click off from the clipper. Place the tramliner blade in a secure place.

Attach the standard blade by lining up the insert with the lug at the bottom of the blade. Slant the blades forward and then click into place.

STARTING AND USING THE CLIPPER

NB – Use on clean, dry hair that is combed until tangle free.

1. Select the correct comb for your desired cutting length.
2. Push the on/off button to activate the clipper. The 'I' symbol will be shown on the on/off button to indicate that the product is switched on.
3. Turning the grooved rotary wheel up or down to position the comb guide to the desired cutting length. It is always suggested to start cutting with the longer length first, then cut again if the length is longer than desired.
4. Hold the clipper against the hair, the teeth of the comb guide should be pointing upwards and flat against the head.
5. Move the clipper upwards and outwards through the hair, a little at a time, against the direction of hair growth. (Fig 1)

Fig 1

6. The clipper will work most efficiently when cutting through the hair at its own speed. Never force through the hair.
7. Never switch the clipper off whilst in the hair.
8. For longer hair on top of your head, you may wish to use the barbers comb to lift the hair and then clip over the comb, or hold the hair between your fingers and cut to the desired length.

- For the finishing touches, that is, around the nape and sideburns, use the clipper without a comb guide. Turn your clipper over and move it from top to bottom. (Fig 2)
- If you want a length greater than 36mm, or if you are experienced, you can create 'comb' and 'finger' cuts:

Fig 2

- Take up a small section of hair with a comb or in your fingers.
- Move the comb or your fingers along the section of hair to the desired length.
- Cut your hair along the comb or your fingers.

- Remove the cut hair using a comb and check the evenness of the cut regularly. (Fig 3)

9. Work around your head in sections.

Fig 3

USING THE PERSONAL GROOMER

The personal groomer included in this grooming kit is designed for trimming nose and ear hair and it safely and quickly trims unwanted hair.

Inserting batteries –

1. The battery compartment cover is located at the back of the trimmer. To remove, simply slide the compartment off the back of the trimmer until it is completely removed from the back of the trimmer.
2. Insert 1x AA alkaline battery, positive end first into the battery compartment. (Alkaline batteries will ensure the best performance and longest life of your appliance). If you are not going to use the unit for a long time, or if the battery is dead, remove the battery from the unit. This will increase the life of your trimmer.
3. To replace the battery compartment cover, simply slide the cover over the back of the trimmer (insert edge first). Slide the cover all the way up the trimmer, until it clicks into place.

To remove hair from the nose and ears –

1. Remove the protective cover from the trimmer and put in a secure place.
2. Switch the product on and gently insert the trimmer into your nostril or ear canal to remove unwanted hair.

3. Rotate trimmer in a circular motion around the opening of the nostril, or ear canal, taking care not to come to close to the border of the nostril or ear. For best results, gently move the trimmer in and out of the nose as you trim ans rotate the hair.

NB – Always remember to turn the trimmer on before you insert into your nostril or ear canal to avoid painfully snagging hairs. Never insert the trimmer more than 6mm into your nose or ear. Use any deeper than this can cause injury.

CLEANING AND MAINTENANCE

To maintain optimum performance, the appliance should be cleaned after each use:

1. Switch trimmer off and remove the power supply, if connected. Remove comb cutting guide.
2. To make cleaning easier, remove the blades from the trimmer. To remove the blades, hold the handle of the trimmer with one hand and place your free hand on top of the trimmer head, with the thumb placed at the back of the blades. Place your index finger and middle at the front of the blades. Using your index and middle fingers, pull the blades backwards and click off from the trimmer. Place the blades in a secure place.
3. Use the cleaning brush supplied to brush away hair and debris.
4. Ensure that you do this after each use and before storing away.
5. When used regularly, the blades will not need to be oiled, however if the trimmer has not been used for a prolonged period of time, then it is advisable to apply a small amount of lubricating oil (provided) to the blades before using. This helps to keep the blades as sharp as possible.

To maintain optimum performance of the personal groomer, it is important to clean away any loose hairs that have collected in the trimmer after use. Regular cleaning will help provide a longer cutting life performance.

1. Ensure that the trimmer is always switched off before cleaning.
2. Thoroughly brush or gently blow away any hair and debris that has built up on the cutters.

BATTERY DISPOSAL

The appliance contains Nickel Metal-Hydrate batteries. To protect the environment, the appliance must be disposed of safely at the end of its useful life. Please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.

Ni-MH

For more information about the recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

LIMITED THREE YEAR WARRANTY

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for thirty-six months from the date of purchase if the appliance is defective in workmanship or materials. This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please fill in and return the Warranty Registration as instructed.

Vidal Sassoon and related logos are trademarks of
The Procter & Gamble Company used under licence by Conair

CONAIR®
©2009 Conair Corporation USA

Conair Australia Pty Ltd, Suites 20 & 21,
7 Narabang Way, Belrose NSW 2085.
Australia Customer Service Hotline (Australia): 1800 650 263
Customer Service e-mail: aus_info@conair.com

Conair New Zealand Limited, PO BOX 251159, Pakuranga, Auckland
1706 New Zealand
Customer Service Hotline (New Zealand): 0800 266 247