

## Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following:

Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

**DANGER:** Unplug unit when not in use. All appliances are electrically live even when switched off.



**WARNING:** This appliance must not be taken into a bathroom.

- Do not immerse in water or other liquids. Do not use in the bath, or near basins or other vessels containing water.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Take care to avoid contact between the hot surfaces of the unit and the skin, paying particular attention to the face, neck and hands.
- This appliance is not intended for use by infirm persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

**IMPORTANT:** Always unplug the appliance when not in use or before cleaning. Do not leave unattended when plugged in or switched on. Do not place on any heat-sensitive surface and always allow to cool before storing away.

- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Use this appliance only for its intended use as described within this instruction booklet.
- This appliance is not intended for commercial use.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Keep the cord away from heated surfaces.
- Do not use an extension cord with this appliance.
- Do not use this appliance if the supply cord is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange.

- After use do not wrap the cord around the appliance as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
- Never drop or insert any object into any opening
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.

## Ultimate 230 Nano Straightener

### Ultimate 230 Nano Straightener

The VS Sassoon Ultimate 230 Nano Straightener is a sleek slimline straightener that features 30% longer plates\* for quicker styling and straightening. It features CeramicTEC™ advanced ceramic heating technology for ultra fast heat-up and heat recovery and reaches a maximum heat of 230°C for seriously straight results. With an internal multi voltage system, perfect for travel, and floating plate for even pressure.

This professional straightener is the ultimate styling tool and allows for styling all hair types, giving you the confidence to achieve your own desired look.



### FEATURES:

1. up to 230°C professional salon heat
2. 30 second instant heat
3. 30% longer slimline plates\* with nano tourmaline ceramic™ coating
4. floating plate
5. multi voltage
6. internal ionic generator with blue ion indicator light
7. CeramicTEC™ advanced ceramic heating technology
8. digital temperature control with 5 variable LED settings: + and – buttons (from 150°C to 230°C)
9. LED variable temperature display
10. on/off switch
11. convenient cool touch covers
12. 3m professional swivel power cord
13. safety cut-off
14. heat protection mat and storage pouch
15. 4 sectioning clips

### Additional features:

- CeramicTEC™ advanced ceramic heating technology
- Nano Tourmaline Ceramic™
- Ionic Conditioning Technology™

## Instructions For Use

### How to use your Ultimate 230 Nano Straightener

1. Remove all packaging and point of sale labels before use.
2. A plastic cover has been placed over the plug to protect it from damage during transportation. Remove the plastic cover from the plug before use.
3. Ensure hair is clean and completely dry before using the appliance.
4. Comb through hair to prevent knots and tangles and then divide hair into equal sections, using the sectioning clips to hold hair in place.
5. Plug the appliance into a 240v power outlet and select your required temperature setting – please see ‘How to use the variable temperature settings’ for more information
6. Place the appliance on a heat protective (such as the heat protection mat), flat level surface
7. Press the ‘on/off’ button to switch the appliance on. The LED display will instantly illuminate green and blue. At this point the straightener will instantly start heating up. The green light indicates that the straightener is on the lowest heat setting - 150°C. The blue light indicates that the internal ionic generator is switched on. As you move through the heat settings, the blue light will always stay illuminated, until the straightener is switched off.
8. Press the ‘+’ or ‘-’ button to adjust to the temperature you desire. The display LED light will change colour according to the temperature you select – please see ‘How to use the variable temperature settings’ for more information. Once the straightener is heated you can begin styling your hair.
9. Style sections of hair until completed.
10. To turn the appliance off, press the ‘on/off’ button. The LED display will turn off. Allow appliance to cool before storing.

**NB:** This appliance has a safety automatic shut-off system, which will automatically turn the appliance off if left switched on accidentally for 72 minutes. If this occurs, please wait for appliance to cool. Switch the appliance off and unplug the power cord.

**WARNING:** This is a high heat appliance. Care must be taken to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.



**IMPORTANT:** Hair that has been heavily bleached or chemically treated should only use the low heat settings on this product. Please consult your hairdresser on using heated appliances if you have any concerns about the condition of your hair.

**How to use the variable temperature settings**

The 5 variable temperature settings/digital heat control provide variable heat for many different hair types. These settings allow you to choose the required temperature setting according to your particular need and hair type.

**NB:** The heat-up time will vary depending on which temperature setting you select. It is suggested to use the lower heat settings when using the appliance for the first time

**WARNING:** This appliance is suitable for average use on the medium high heat setting of 190°C. The 210°C and 230°C maximum high heat settings are not suitable for hair that has been chemically treated, bleached or damaged.

**DO NOT USE THIS PRODUCT ON HEAT DAMAGED OR CHEMICALLY DAMAGED HAIR ON THE HIGHER HEAT SETTINGS.**

Temperature Setting Guide	
Variable Temperature Control Settings	Hair Type
Power/Low setting - 150°C	Delicate, fine, bleached hair
Medium setting - 170°C	Average to thick treated hair
Medium high setting - 190°C	Normal, thick or wavy hair
High setting - 210°C	Hard to straighten, thick hair
**Maximum setting - 230°C	Hard to straighten, very thick curly hair

**\*\*IMPORTANT: When using the appliance on maximum heat - 230°C setting:**

When using the appliance on the maximum heat setting it is recommended to place the cool touch covers over the ends of the straightener. To use the cool touch covers, simply slide one cover over the top of the straightener and the other on the bottom of the straightener. These provide extra protection when styling very thick curly hair and/or creating curls with your straightener.

To remove the covers, simply slide the covers off the ends of the straightener and place in the protective carry pouch for storage.



**How to use the heat protection mat/storage pouch?**

The heat protection mat also doubles as an instant storage pouch. To use the pouch as a heat protection mat, simply unclick and unfold the pouch until it opens completely. Place the straightener on the silver heat protection surface and begin styling your hair. The storage pouch at the end of the mat can also be removed for more convenient styling. To remove, simply unclick the storage pouch from the end of the mat.

After use, the straightener can be placed inside the pouch for storage. (If the storage pouch has been removed from the mat, place the storage pouch at the end of the mat, by clicking into place). Ensure that the appliance is switched off and has cooled down before storing. To use the storage pouch, unzip the pouch until it is completely open. Ensure that the silver divider is standing upright before placing the appliance inside the pouch. Simply place the straightener on one side of the silver divider and the power cord and plug on the other side of the divider. Never allow the plates to touch the power cord or plug, as this may scratch the surface of the straightener and/or the straightening plates. To close, simply zip the storage pouch closed and fold the heat mat up and then click the pouch together.

**Multi Voltage**

This straightener has a multi voltage feature for worldwide use. The voltage automatically converts for ease of use from 100V - 240V. NOTE: This straightener has an internal automatic converter which will automatically convert the voltage without the need of a switch. A suitable plug adaptor will be required.

**How does the ionic feature work?**

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution add to the build-up of static electricity in the hair. Even brushing and towel-drying the hair can increase these levels. This static charge causes the scales, or cuticles of the hair, to push hair strands apart, resulting in a rough hair surface. Consequently, hair may have a dull appearance. High levels of static charge cause hair to become 'flyaway' and difficult to style. The advanced internal ionic generator conditions hair by emitting negative ions to reduce static, by leaving hair silky and shiny with reduced frizz.

**What is the CeramicTEC™ advanced ceramic heating technology?**

This straightener features a microprocessor controlled professional ceramic heater for perfect results by intelligently maintaining a high heat level. The internal ceramic heater allows for ultra fast heat up and consistent heat delivery. This system provides consistent styling power so that every strand of hair is set with the same level of heat and comes out the same way, for a perfect, flawless finish.

**What is Nano Tourmaline Ceramic™?**

Nano Tourmaline Ceramic™ technology unites micro particles of nano silver, tourmaline and ceramic and when combined with heat seals the hair cuticle for reduced frizz and enhanced shine.

**User Maintenance**

Your styler is designed for household use and is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of lint and other debris. If cleaning becomes necessary, disconnect the appliance from the power outlet. Allow the appliance to cool and wipe exterior with a cloth. If any abnormal conditions occur, allow to cool and return to your place of purchase.

**Limited Three Year Warranty**

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for thirty-six months from the date of purchase if the appliance is defective in workmanship or materials. This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please fill in and return the Warranty Registration as instructed.

**CONAIR®**

Vidal Sassoon and related logos are trademarks of The Procter & Gamble Company used under licence by Conair

©2008 Conair Corporation USA, 1 Cummings Point Rd, Stamford, Connecticut, 06902 USA

Conair Australia Pty Ltd  
Suites 20 and 21,  
7 Narabang Way, Belrose NSW 2085  
Customer Service Hotline (Australia): 1800 650 263

Customer Service e-mail: [aus\\_info@conair.com](mailto:aus_info@conair.com)  
Visit us at [www.vssassoon.com.au](http://www.vssassoon.com.au)

Conair New Zealand Ltd.,  
PO Box 251159, Pakuranga, Auckland, 1706, New Zealand  
Customer Service Hotline (New Zealand): 0800 266 247

premiere series

**Ultimate 230 Nano Straightener**

VSP2089A