

## Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following: Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

**DANGER:** Unplug unit when not in use. All appliances are electrically live even when switched off.



**WARNING:** This appliance must not be taken into a bathroom.

- Do not immerse in water or other liquids. Do not use in the bath, or near basins or other vessels containing water.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Take care to avoid contact between the hot surfaces of the unit and the skin, paying particular attention to the face, neck and hands.
- This appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

**IMPORTANT:** Always unplug the appliance when not in use or before cleaning. Do not leave unattended when plugged in or switched on. Do not place on any heat-sensitive surface and always allow to cool before storing way.


- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Use this appliance only for its intended use as described within this instruction booklet.
- This appliance is not intended for commercial use.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Keep the cord away from heated surfaces.
- Do not use an extension cord with this appliance.

- Do not use this appliance if the supply cord is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange.
- After use do not wrap the cord around the appliance as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
- Never drop or insert any object into any opening
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.

## Goddess Conditioning Ionic Steam Straightener

### Goddess Conditioning Ionic Steam Straightener

The VS Sassoon Goddess Straightener is a professional straightener with steam that adds moisture and shine to hair with ultra straight results. It provides more shine, faster straightening and longer lasting results. It features CeramicTEC™ advanced ceramic heating technology for ultra fast heat-up and heat recovery and reaches a maximum heat of 230°C for seriously straight results.



### FEATURES:

1. Up to 230°C professional salon heat
2. 30 second instant heat
3. Total conditioning system adds moisture and shine
4. Water reservoir for optional gentle conditioning steam
5. Steam function switch: 3 positions - no steam/normal/high
6. Nano silver & tourmaline ceramic™ plates
7. Internal ionic generator with blue ion indicator light
8. CeramicTEC™ advanced ceramic heating technology
9. Digital temperature control with 5 LED variable settings: + and - buttons (from 170°C to 230°C)
10. LED variable temperature display
11. On/off switch
12. Switch for retractable detangling combs : 3 positions - no comb/medium comb for fine hair/long comb for thick hair
13. Cool tips
14. Professional swivel power cord
15. Luxury heat protection mat
16. Automatic cut-off system

### Additional features:

- CeramicTEC™ advanced ceramic heating technology
- Nano silver & Tourmaline Ceramic™
- Ionic Conditioning Technology™
- Pure gentle conditioning steam

## Instructions For Use

### How to use your Goddess conditioning ionic steam straightener

1. Remove all packaging and point of sale labels before use.
2. A plastic cover has been placed over the plug to protect it from damage during transportation. Remove the plastic cover from the plug before use.
3. Ensure hair is clean and completely dry before using the appliance.
4. Comb through hair to prevent knots and tangles and then divide hair into equal sections.
5. Remove the water reservoir (4) located at the top of the unit and lift the black rubber button. Fill it with water, preferably filtered water, and replace black button. Then put the reservoir back on the straightener.
6. Check that the reservoir is properly positioned and closed.
7. Check that the outside of the reservoir and your hands are dried well.
8. If the reservoir is full, you can use the steam function. If you have to fill the reservoir a second time, unplug the unit and replace the reservoir immediately after filling it, making sure you don't touch the hot plates.
9. Let the unit heat up for at least 2 - 3 minutes before using the steam function.
10. Avoid any contact between the hot surfaces and your face or neck. Make sure you do not direct the steam at your face or neck.
11. Plug the appliance into a 240v power outlet.
12. Place the appliance on a heat protective (such as the heat protection mat), flat level surface.
13. Press the on/off button (11) to switch the appliance on. The LED display: will instantly illuminate. At this point the straightener will instantly start heating up. The green light indicates that the straightener is on the lowest heat setting - 170 °C. Select your required temperature setting – please see 'How to use the variable temperature settings' for more information. The blue light indicates that the internal ionic generator is switched on. As you move through the heat settings, the blue light will always stay illuminated, until the straightener is switched off.

### How to use your Goddess conditioning ionic steam straightener with Steam

On first use with the steam, or if the unit has not been used for a while, start up the steam function by closing and opening the unit 7 - 8 times ( a pumping action)

1. Switch the steam function on (5).
2. Select the desired steam output no steam, normal or high
3. Select the desired position of the retractable detangling comb. The detangling comb will allow hair to spread evenly between the teeth of the comb to untangle your hair with ease.
4. Straighten your hair from root to tip.

### How to use your Goddess conditioning ionic steam straightener without Steam

1. Slide the steam function switch into the 'no steam' position or use the straightener with an empty reservoir.
  2. Next follow points 11. to 13. under Instructions for Use.
- Additionally, you can perfect and set your hair using one stroke with steam and then a second stroke without steam.

**NB:** This appliance has a safety automatic shut-off system, which will automatically turn the appliance off if left switched on accidentally for 72 minutes. If this occurs, please wait for appliance to cool. Switch the appliance off and unplug the power cord.

**WARNING:** This is a high heat appliance. Care must be taken to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.

**IMPORTANT:** Hair that has been heavily bleached or chemically treated should only use the low heat settings on this product. Please consult your hairdresser on using heated appliances if you have any concerns about the condition of your hair.

### How to use the variable temperature settings

The 5 variable temperature settings/digital heat control provide variable heat for many different hair types. These settings allow you to choose the required temperature setting according to your particular need and hair type.

**NB:** The heat-up time will vary depending on which temperature setting you select. It is suggested to use the lower heat settings when using the appliance for the first time.

**WARNING:** This straightener gets extremely hot. It is recommended to always start with the lowest temperature setting and adjust it accordingly after the first use, depending on the results and your hair type

TEMPERATURES	HAIR TYPES	STEAM OUTPUT
170°C green LED 185°C yellow LED	Fragile hair: fine, dry, bleached, damaged and/or frizzy Wavy hair	High High
185°C yellow LED 200°C orange LED	Normal or coloured hair Wavy to loosely curly hair	High Medium
200°C orange LED 215°C red LED 230°C red LED	Thick hair Curly to very curly hair	Medium Medium

### How to use the heat protection mat

To use the heat protection mat, simply unfold the mat until it opens completely. Place the straightener on the silver heat protection surface and begin styling your hair.

After use, the heat mat can be used as a storage roll. Ensure the appliance is switched off and has cooled down before storing. Simply place the straightener with cord on one end of the heat mat and roll heat mat around straightener.

### How does the ionic feature work?

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution add to the build-up of static electricity in the hair. Even brushing and towel-drying the hair can increase these levels. This static charge causes the scales, or cuticles of the hair, to push hair strands apart, resulting in a rough hair surface. Consequently, hair may have a dull appearance.

High levels of static charge cause hair to become 'flyaway' and difficult to style. The advanced internal ionic generator conditions hair by emitting negative ions to reduce static, by leaving hair silky and shiny with reduced frizz.

### What is the CeramicTEC™ advanced ceramic heating technology?

This straightener features a microprocessor controlled professional ceramic heater for perfect results by intelligently maintaining a high heat level. The internal ceramic heater allows for ultra fast heat up and consistent heat

delivery. This system provides consistent styling power so that every strand of hair is set with the same level of heat and comes out the same way, for a perfect, flawless finish.

### What is Nano Silver & Tourmaline Ceramic™?

Nano Silver & Tourmaline Ceramic™ technology unites micro particles of nano silver, tourmaline and ceramic for a unique combination that reduces static and quickly seals the hair cuticle layer, to leave hair with reduced frizz and increased shine.

### User Maintenance

Your styler is designed for household use and is virtually maintenance free. If cleaning becomes necessary, disconnect the appliance from the power outlet. Make sure you empty the water reservoir after every use. It is preferable to use filtered water to fill the reservoir. Otherwise take care to descale the reservoir from time to time. Keep all vents and openings clear of lint and other debris. Allow the appliance to cool and wipe exterior with a cloth. If any abnormal conditions occur, allow to cool and return to your place of purchase. Store the straightener with plates pressed together to protect them.

### Limited Three Year Warranty

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for thirty-six months from the date of purchase if the appliance is defective in workmanship or materials. This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please fill in and return the Warranty Registration as instructed.

### CONAIR®

Vidal Sassoon and related logos are trademarks of The Procter & Gamble Company used under licence by Conair

©2008 Conair Corporation USA,  
1 Cummings Point Rd,  
Stamford, Connecticut, 06902 USA

Conair Australia Pty Ltd  
Suites 20 and 21,  
7 Narabang Way, Belrose NSW 2085

Customer Service Hotline (Australia):  
1800 650 263

Customer Service e-mail: [aus\\_info@conair.com](mailto:aus_info@conair.com)

Conair New Zealand Ltd.,  
PO Box 251159, Pakuranga, Auckland, 1706,  
New Zealand  
Customer Service Hotline (New Zealand):  
0800 266 247

**VS**  
SASSOON

premiere series

Goddess straightener  
conditioning ionic steam