

VS
SASSOON

FOR MEN



THE
BEARDED
PRO



TOOL TIPS

for the rechargeable beard & stubble trimmer with beard comb
+ beard brush + BONUS Milkman beard balm.

VSM7843A

HEY YOU!
TAKE A BOW FINE SIR.

THINGS ARE LOOKING UP
& **YOU'VE JUST MADE A
QUALITY PURCHASE**
WITH THIS NEW GROOMING TOOL.

WE KNOW YOU'VE GOT THIS, BUT BEFORE YOU JUMP INTO
USING YOUR NEW SIDE KICK, HERE'S A FEW TIPS & TRICKS
TO KNOW BEFORE LETTING YOUR CREATIVITY RUN LOOSE.

HIT UP VSFORMEN.COM.AU FOR MORE GROOMING & INSPIRATION.



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following:

Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

DANGER: When the unit is used in a bathroom, unplug it from the mains power after use since the proximity of water presents a hazard even when the appliance is switched off.



WARNING: Do not use or leave the AC power adaptor in a position where it can become wet or there is a danger of it falling into a basin or other vessels containing water. Keep the appliance dry, unless it otherwise specified.

- Do not immerse appliance in water or other liquids.
- Do not reach for an appliance that has fallen into water and is connected to mains power. Unplug immediately.
- Take care to avoid contact between the moving blades of the unit and the skin, paying particular attention to the face, neck and hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

IMPORTANT: Always unplug the appliance when not in use or before cleaning. Do not leave unattended when plugged in or switched on. Do not place on any heat sensitive surface.

- Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
- Use this appliance only for its intended use as described within this instruction booklet.
- Always unplug the appliance when fully charged.
- This appliance is not intended for commercial use.
- Never drop or insert any object into an opening.
- Do not use the appliance with damaged or broken attachment combs or with any teeth missing from the blades, as injury may occur.
- Do not place on any surface while it is operating.
- Keep the cord away from heated surfaces
- Never twist or pull on the power cord.
- Do not use an extension cord with this appliance.
- After use do not wrap the cord around the appliance as in time this may cause the cord to fracture. Coil cord loosely by the side of the appliance in storage.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use the appliance if it is damaged. In the event of damage, discontinue use immediately and contact your dealer for instructions on returning it for examination or exchange. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.

THE BEARDED-PRO GROOMING GIFT SET

BRAVO. YOU'VE MADE A QUALITY PURCHASE.

The Bearded-Pro gives you the power to shape your world. Prep your facial hair, then trim, shape & define. Finish with Milkman's Beard Balm to condition, add style & lustre to any bearded or stubble look.



BEARD & STUBBLE TRIMMER

1. Cordless use
2. Precision W-Tech blades
3. 1 comb guide with 30 positions (0.5mm to 15mm) for crafting a short stubble look, or keeping your beard in top shape
4. Integrated grooved wheel adjusts trimming settings in 0.5mm steps
5. 100% waterproof
6. Cleaning brush

+ BEARD COMB

Ideal for tidying & styling moustaches, beard & stubble. Perfect for prepping hair prior to trimming.

+ BEARD BRUSH

Untangles, softens & smoothes beard & stubble. Helps to eliminate dead skin cells, while revitalizing & rejuvenating skin to prep for trimming.

+ BONUS MILKMAN BEARD BALM

Adds style & lustre to any bearded look.

PREPPING YOUR NEW RECHARGEABLE BEARD & STUBBLE TRIMMER

CHARGING

The Bearded-Pro Beard & Stubble Trimmer is so easy to use. But before you start using your new tool, you must take the time to charge it overnight for **16 hours** before its first use. Your new tool comes with a small amount of charge, but the initial charge will ensure your new tool will have optimum power performance to give you smooth fast cutting, every time.

- Before using for the first time, fully charge your new tool continuously for 16 hours.
- Maximum battery capacity will only be reached after 3 charging & discharging cycles.
- Ensure your new tool is switched off.
- Insert the small plug on the charging adaptor into the socket on the bottom of your new tool.
- Plug the charging adaptor into a suitable mains power socket and switch on. If the battery is very weak, wait about 1 minute.
- The red charging LED indicator light on your new tool will flash when correctly connected to the mains power. When it is fully charged, the red charging LED indicator light will remain on.
- A full charge will supply 40 minutes cordless runtime.
- Subsequent recharges will only require 8 hours charging time.
- To maintain optimum capacity of the rechargeable battery, it is highly recommended to fully discharge & then recharge your tool for 16 hours every 3 months.

HOW TO USE THE RECHARGEABLE BEARD & STUBBLE TRIMMER

BEFORE USING

- Always inspect the trimmer blades for noticeable signs of damage.
- Always inspect the trimmer blades before use to ensure they are free from hair, debris etc.
- Ensure the trimmer is sufficiently charged before use.
- For best performance use on clean, dry hair that has been combed until tangle-free.

SELECTING A CUTTING LENGTH

The Bearded-Pro Beard & Stubble Trimmer comes with 1 comb guide with 30 positions (0.5mm to 15mm) for crafting a short stubble look, or keeping your beard in top shape and an integrated grooved wheel control that adjusts the trimming settings in 0.5mm steps. Simply turn the wheel up and down to your desired cutting length setting.

GOOD TO NOTE: Always put the comb guide on BEFORE turning the trimmer on, and turn the trimmer off before removing it.

To remove the comb guide, set the comb guide so its aligned with the triangle mark (Fig. 1). With the trimmer switched off, pull the comb guide up to remove it.

To replace the comb guide, set the comb guide to the triangle mark (Fig. 1). With the trimmer switched off, press the comb guide down then turn the dial to put it on.




Fig.1

GET IT WET IN THE SHOWER OR SIMPLY USE DRY. YOUR CALL.

The Bearded-Pro Beard & Stubble Trimmer is designed for trimming wet in the shower, or you can use it dry. Your call!

WARNING: The power cord of the adaptor must be unplugged from the handle before using your trimmer in the shower. The charging power adaptor is not waterproof. It should always remain dry.

TRIMMING TIPS

Hit up www.vsformen.com.au for more grooming tips & inspiration.

Before trimming your beard or stubble:

- a. Use the **beard comb** use prior to trimming to help prep hair by combing through until tangle-free, then;
- b. Use the **beard brush** to help untangle, soften and smooth. Using the beard brush before trimming also helps to eliminate dead skin cells, while revitalizing & rejuvenating skin to prep for trimming.

USING THE BEARD & STUBBLE TRIMMER TRIMMING BLADES + COMB GUIDE

1. Switch the trimmer on by sliding the On/Off switch upwards so that the "I" marking is visible.
2. Select your desired cutting length. To adjust the cutting length of your trimmer, simply turn the wheel up and down (clockwise and anti-clockwise) to your desired cutting length setting. If trimming longer than 6mm, it's advised to move the short beard guide to the back of the trimmer.
3. When trimming, hold the comb guide flat against the skin. For the most precise, consistent trim, the tips of the teeth and the little corners protruding from the comb should always be in contact with the skin. If not, the precision of the cut may change. (Fig. 2-3).
4. It is suggested to trim the hair in the direction of hair growth, as trimming against the direction of growth could cause a rash or irritation.
5. Pull the skin firmly with one hand during the trimming process to ensure the closest trim possible.
6. Move the trimmer slowly and carefully, so as not to cut any hair you do not intend to trim.
7. Trim, shape and define your facial hair as needed.



Fig.2




Fig.3

NOTE: Be careful not to apply excess pressure to the blade, as this may damage the blade and can result in injury to the skin during trimming.

USING THE MILKMAN BEARD BALM

Use the Milkman Beard Candy Beard Balm to add style and lustre to any bearded look.

Directions: Scrape a small amount of beard balm in your fingertips & rub together until it dissolves, then work through your beard & style as preferred.

Caution: Patch test before use. Store in a cool dark place. Discard 12 months after opening. Not for consumption. Keep out of reach of children.

To find out more on Milkman, or where to buy Milkman products, head to
www.milkmanaustralia.com
www.facebook.com/milkmanaustralia
www.instagram.com/milkmanaustralia
[#freshbetweentheears](https://twitter.com/freshbetweentheears)

Ingredients: Bees Wax, Cocos Nucifera (Coconut Oil), Simmondsia Chinensis (Jojoba) Seed Oil, Cannabis Sativa (Hemp) Seed Oil, Argonia Spinosa (Argan) Oil, Persea Gratissima (Avocado) Oil, Camellia Sinensis Leaf (Camellia) Oil, Olea Europaea Fruit (Olive) Oil, Microcrystalline Wax, Copernicia Cerifera (Carnauba) Wax, Juniperus Mexicana (Cedar) Oil, Sandalwood Fragrant Oil, D-alpha-Tocopherol (Vitamin E), Parfum (Fragrance), Glycine Soja Oil, Eugenia Caryophyllus Bud (Clove) Oil.
MADE IN AUSTRALIA

BEARD & STUBBLE TRIMMER CLEANING & MAINTENANCE

Because the trimmer blades are precision made for a very special use, they should always be handled with care. To ensure long-lasting performance of your trimmer, it is important to clean the blades + the comb guide after every use.

The blades are washable for easy cleaning.

To remove the trimming blade:

1. Before changing the attachment heads, make sure your trimmer is switched off.
2. Remove the comb guide from your trimmer.
3. To remove the trimming blade, push the tip of the blade upwards and away from you using your thumb (Fig.4).




Fig.4

To clean the blades:

1. First, take a small brush and brush away any loose hairs that have collected in the blades.
2. Rinse the trimming blades under running water. The comb guide can also be rinsed separately.
3. After cleaning, make sure to shake off excess water and dry the head of the trimming blades + comb guide before replacing onto the handle.

OIL FREE TRIMMING BLADES, THE WAY IT SHOULD BE

The blades of your trimmer have a reservoir pad for releasing the necessary amount of oil for proper operation, time after time. Nevertheless, it is recommended that the reservoir pad be refilled occasionally when you notice cutting performance is not as high.

To remove the trimming blade, follow the instructions above to remove the trimming blade. Squeeze a few drops of oil onto the reservoir pad (Fig. 5). Then replace the blades on the trimmer.








Fig.5

WORLDWIDE VOLTAGE

This appliance has a multi voltage feature for worldwide use. The voltage automatically converts for ease of use from 100v - 240v. This appliance has an automatic internal converter which will automatically convert the voltage without the need of a switch. A suitable plug adaptor will be required, please refer to the chart below.

Plug adaptor required	Voltage and plug adaptors	Country	Voltage setting
	British plug: 240V	Ireland, Great Britain, Singapore, South America, Hong Kong (parts only), Africa (parts only)	240V
	European plug: 240V	Asia, Europe, Middle East Noumea, Scandinavia, South America, Hong Kong (parts only)	240V
	Australian and New Zealand plug: 240V	Australia, New Zealand	240V
	American plugs: 120V	North America, Japan, Canada (parts of)	120V

BATTERY DISPOSAL

The Bearded-Pro Beard & Stubble Trimmer contains a Nickel Metal-Hydride battery. To protect the environment, the appliance must be disposed of safely at the end of its useful life.



Please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.

Ni-MH

For more information about the recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

**TO MAKE A WARRANTY CLAIM YOU MUST
RETAIN YOUR PROOF OF PURCHASE.**

LIMITED TWO YEAR WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

Conair Australia Pty Ltd will repair or replace (at our option) your appliance free of charge for twenty-four months from the date of purchase if the appliance is defective in workmanship or materials.

This warranty only covers the rechargeable beard & stubble trimmer included in The Bearded-Pro Grooming Gift Set. It does not include the beard comb, beard brush or Milkman beard balm.

This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please read the Warranty Leaflet included or contact Conair Customer Service at aus_info@conair.com.

•



Vidal Sassoon and related logos are trademarks of
The Procter & Gamble Company used under license by Conair.

©2017 Conair Australia Pty. Ltd.
Suite 101, 18 Rodborough Rd
Frenchs Forest NSW 2086
Australia

Conair New Zealand Limited
PO BOX 251159
Pakuranga, Auckland 1706
New Zealand

CONTACT US

For advice & tips on your new VS product email us on:
aus_info@conair.com

CUSTOMER SERVICE

Australia: 1800 650 263
New Zealand: 0800 266 247

Visit VSFORMEN.COM.AU for grooming tips & inspiration.

VS
SASSOON

FOR MEN

**YOU WERE
BORN TO
BE REAL,
NOT TO BE
PERFECT**

IB-17/171